


## Pneumatic Tube Fittings

### Feature

- One-Touch push-to-connect configuration allows an instant tubing connection.
- Smooth-Edge release sleeve design facilitates a quick tubing disconnection.
- Aesthetically pleasing nickel-plated metallic optional feature ensures anti-corrosion and anti-contamination properties of an extended product life.
- Pre-applied sealant on all external threads eliminates the additional sealing requirement.
- Internal and/of external flat-to-flat hexagonal configurations for both metric and inch specifications allow a proper tightening or directional orientation upon installation by using L key or allen wrench for the applicable model types.

### Construction



### Specification

Fluid Type	Air, Vacuum
Operating Pressure	0-10.2Kgf/cm <sup>2</sup> (0-1.0Mpa)
Negative Pressure	-750mm Hg(10Torr)
Operating Temperature Range	0-60°C
Tube Material	Nylon and Polyurethane

### (1) Model Type

### (2) Tube Outer Diameter(ΦD)

Metric Tube				Inch Tube							
Code	04	06	08	10	12	14	16	1/4"	5/16"	3/8"	<input type="checkbox"/>
ΦD	4mm	6mm	8mm	10mm	12mm	14mm	16mm	1/4"	5/16"	3/8"	<input type="checkbox"/>

### (3) Thread Type & Size


#### Metric Size

Metric Size			
Code	M5	M6	M8
Size	M5×0.8	M6×1	M8×1

### (4) Body Color Code

- NO Code: Black Color
- GC: Grey Color

### Ordering Code



#### Taper Pipe Thread

R(PT) Thread				
Code	01	02	03	04
Size	R1/8"	R1/4"	R3/8"	R1/2"

#### Inch Thread

G(PP) Thread				
Code	G01	G02	G03	G04
Size	G1/8"	G1/4"	G3/8"	G1/2"

#### NPT Thread

NPT Thread				
Code	N1	N2	N3	N4
Size	NPT1/8"	NPT1/4"	NPT3/8"	NPT1/2"

## XPC

ΦD



T

### MODEL(ΦD-T)

Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)			
XPC 04-M5	XPC 06-04	XPC 12-02	XPC 1/4-01	XPC 3/8-04	XPC 5/32-U	XPC 1/4-N2	XPC 1/2-N2
XPC 04-M6	XPC 08-01	XPC 12-03	XPC 1/4-02	XPC 1/2-02	XPC 5/32-N1	XPC 1/4-N3	XPC 1/2-N3
XPC 04-01	XPC 08-02	XPC 12-04	XPC 1/4-03	XPC 1/2-03	XPC 5/32-N2	XPC 5/16-N1	XPC 1/2-N4
XPC 04-02	XPC 08-03	XPC 14-03	XPC 5/16-01	XPC 1/2-04	XPC 3/16-U	XPC 5/16-N2	
XPC 06-M5	XPC 08-04	XPC 14-04	XPC 5/16-02		XPC 3/16-N1	XPC 5/16-N3	
XPC 06-M6	XPC 10-01	XPC 16-03	XPC 5/16-03		XPC 3/16-N2	XPC 3/8-N1	
XPC 06-01	XPC 10-02	XPC 16-04	XPC 3/8-01		XPC 3/16-N3	XPC 3/8-N2	
XPC 06-02	XPC 10-03		XPC 3/8-02		XPC 1/4-U	XPC 3/8-N3	
XPC 06-03	XPC 10-04		XPC 3/8-03		XPC 1/4-N1	XPC 3/8-N4	

## XPOC

ΦD



T

### MODEL(ΦD-T)

Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPOC 04-M5	XPOC 06-03	XPOC 10-04	XPOC 1/4-01	XPOC 5/32-U	XPOC 3/8-N2	
XPOC 04-M6	XPOC 08-01	XPOC 12-02	XPOC 1/4-02	XPOC 5/32-N1	XPOC 3/8-N3	
XPOC 04-01	XPOC 08-02	XPOC 12-03	XPOC 5/16-01	XPOC 1/4-U	XPOC 3/8-N4	
XPOC 04-02	XPOC 08-03	XPOC 12-04	XPOC 5/16-02	XPOC 1/4-N1	XPOC 1/2-N2	
XPOC 06-M5	XPOC 08-04	XPOC 14-03	XPOC 5/16-03	XPOC 1/4-N2	XPOC 1/2-N3	
XPOC 06-M6	XPOC 10-01	XPOC 14-04	XPOC 3/8-02	XPOC 5/16-N1	XPOC 1/2-N4	
XPOC 06-01	XPOC 10-02	XPOC 16-03	XPOC 3/8-03	XPOC 5/16-N2		
XPOC 06-02	XPOC 10-03	XPOC 16-04	XPOC 3/8-04	XPOC 5/16-N3		

## Pneumatic Tube Fittings

## XPL



T

ΦD

### MODEL(ΦD-T)

Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)			
XPL 04-M5	XPL 06-04	XPL 12-02	XPL 1/4-01	XPL 3/8-04	XPL 5/32-U	XPL 1/4-N2	XPL 1/2-N2
XPL 04-M6	XPL 08-01	XPL 12-03	XPL 1/4-02	XPL 1/2-02	XPL 5/32-N1	XPL 1/4-N3	XPL 1/2-N3
XPL 04-01	XPL 08-02	XPL 12-04	XPL 1/4-03	XPL 1/2-03	XPL 5/32-N2	XPL 5/16-N1	XPL 1/2-N4
XPL 04-02	XPL 08-03	XPL 14-03	XPL 5/16-01	XPL 1/2-04	XPL 3/16-U	XPL 5/16-N2	
XPL 06-M5	XPL 08-04	XPL 14-04	XPL 5/16-02		XPL 3/16-N1	XPL 5/16-N3	
XPL 06-M6	XPL 10-01	XPL 16-03	XPL 5/16-03		XPL 3/16-N2	XPL 3/8-N1	
XPL 06-01	XPL 10-02	XPL 16-04	XPL 3/8-01		XPL 3/16-N3	XPL 3/8-N2	
XPL 06-02	XPL 10-03		XPL 3/8-02		XPL 1/4-U	XPL 3/8-N3	
XPL 06-03	XPL 10-04		XPL 3/8-03		XPL 1/4-N1	XPL 3/8-N4	

## XPLL



T

ΦD

### MODEL(ΦD-T)

Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)	
XPLL 04-M5	XPLL 06-04	XPLL 12-02	XPLL 1/4-01	XPLL 5/32-U	XPLL 5/16-N2
XPLL 04-M6	XPLL 08-01	XPLL 12-03	XPLL 1/4-02	XPLL 5/32-N1	XPLL 5/16-N3
XPLL 04-01	XPLL 08-02	XPLL 12-04	XPLL 5/16-02	XPLL 3/16-N1	XPLL 3/8-N2
XPLL 04-02	XPLL 08-03	XPLL 14-03	XPLL 3/8-02	XPLL 3/16-N2	XPLL 3/8-N3
XPLL 06-M5	XPLL 08-04	XPLL 14-04	XPLL 3/8-03	XPLL 3/16-N3	XPLL 3/8-N4
XPLL 06-M6	XPLL 10-01	XPLL 16-03		XPLL 1/4-N1	XPLL 1/2-N2
XPLL 06-01	XPLL 10-02	XPLL 16-04		XPLL 1/4-N2	XPLL 1/2-N3
XPLL 06-02	XPLL 10-03			XPLL 1/4-N3	XPLL 1/2-N4
XPLL 06-03	XPLL 10-04			XPLL 5/16-N1	

## XPLF



T

ΦD

### MODEL(ΦD-T)

Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)		
XPLF 04-M5	XPLF 08-01	XPLF 12-03	XPLF 5/32-N1	XPLF 3/8-N3
XPLF 04-M6	XPLF 08-02	XPLF 12-04	XPLF 3/16-N1	XPLF 1/2-N3
XPLF 04-01	XPLF 08-03	XPLF 14-03	XPLF 3/16-N2	XPLF 1/2-N4
XPLF 04-02	XPLF 08-04	XPLF 14-04	XPLF 1/4-N1	
XPLF 06-M5	XPLF 10-01	XPLF 16-03	XPLF 1/4-N2	
XPLF 06-M6	XPLF 10-02	XPLF 16-04	XPLF 5/16-N1	
XPLF 06-01	XPLF 10-03		XPLF 5/16-N2	
XPLF 06-02	XPLF 10-04		XPLF 5/16-N3	
XPLF 06-03	XPLF 12-02		XPLF 3/8-N2	

## XPCF

ΦD



T

### MODEL(ΦD-T)

Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)	
XPCF 04-01	XPCF 10-01	XPCF 1/4-01	XPCF 5/32-N1	XPCF 3/8-N2	
XPCF 04-02	XPCF 10-02	XPCF 1/4-02	XPCF 5/32-N2	XPCF 3/8-N3	
XPCF 06-01	XPCF 10-03	XPCF 5/16-01	XPCF 3/16-N1	XPCF 1/2-N2	
XPCF 06-02	XPCF 10-04	XPCF 5/16-02	XPCF 3/16-N2	XPCF 1/2-N3	
XPCF 06-03	XPCF 12-02	XPCF 3/8-02	XPCF 1/4-N1		
XPCF 08-01	XPCF 12-03	XPCF 3/8-03	XPCF 1/4-N2		
XPCF 08-02	XPCF 12-04		XPCF 5/16-N1		
XPCF 08-03	XPCF 16-03		XPCF 5/16-N2		
XPCF 08-04	XPCF 16-04		XPCF 5/16-N3		

## XPB



T

ΦD

### MODEL(ΦD-T)

Tube(Metric)-Thread(R)		Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)			
XPB 04-M5	XPB 06-04	XPB 12-02	XPB 1/4-01	XPB 3/8-04	XPB 5/32-U	XPB 1/4-N2	XPB 1/2-N2
XPB 04-M6	XPB 08-01	XPB 12-03	XPB 1/4-02	XPB 1/2-02	XPB 5/32-N1	XPB 1/4-N3	XPB 1/2-N3
XPB 04-01	XPB 08-02	XPB 12-04	XPB 1/4-03	XPB 1/2-03	XPB 5/32-N2	XPB 5/16-N1	XPB 1/2-N4
XPB 04-02	XPB 08-03	XPB 14-03	XPB 5/16-01	XPB 1/2-04	XPB 3/16-U	XPB 5/16-N2	
XPB 06-M5	XPB 08-04	XPB 14-04	XPB 5/16-02		XPB 3/16-N1	XPB 5/16-N3	
XPB 06-M6	XPB 10-01	XPB 16-03	XPB 5/16-03		XPB 3/16-N2	XPB 3/8-N1	
XPB 06-01	XPB 10-02	XPB 16-04	XPB 3/8-01		XPB 3/16-N3	XPB 3/8-N2	
XPB 06-02	XPB 10-03		XPB 3/8-02		XPB 1/4-U	XPB 3/8-N3	
XPB 06-03	XPB 10-04		XPB 3/8-03		XPB 1/4-N1	XPB 3/8-N4	



**Pneumatic Tube Fittings**


**XPD**



MODEL(ΦD-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPD 04-M5	XPD 06-04	XPD 12-02	XPD 1/4-01	XPD 3/8-04	XPD 5/32-U	XPD 1/4-N2	XPD 1/2-N2
XPD 04-M6	XPD 08-01	XPD 12-03	XPD 1/4-02	XPD 1/2-02	XPD 5/32-N1	XPD 1/4-N3	XPD 1/2-N3
XPD 04-01	XPD 08-02	XPD 12-04	XPD 1/4-03	XPD 1/2-03	XPD 5/32-N2	XPD 5/16-N1	XPD 1/2-N4
XPD 04-02	XPD 08-03	XPD 14-03	XPD 5/16-01	XPD 1/2-04	XPD 3/16-U	XPD 5/16-N2	
XPD 06-M5	XPD 08-04	XPD 14-04	XPD 5/16-02		XPD 3/16-N1	XPD 5/16-N3	
XPD 06-M6	XPD 10-01	XPD 16-03	XPD 5/16-03		XPD 3/16-N2	XPD 3/8-N1	
XPD 06-01	XPD 10-02	XPD 16-04	XPD 3/8-01		XPD 3/16-N3	XPD 3/8-N2	
XPD 06-02	XPD 10-03		XPD 3/8-02		XPD 1/4-U	XPD 3/8-N3	
XPD 06-03	XPD 10-04		XPD 3/8-03		XPD 1/4-N1	XPD 3/8-N4	

**XPX**



MODEL(ΦD-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)		
XPX 04-M5	XPX 06-04	XPX 12-02	XPX 1/4-01	XPX 3/8-04	XPX 5/32-U	XPX 1/4-N2	XPX 1/2-N2
XPX 04-M6	XPX 08-01	XPX 12-03	XPX 1/4-02	XPX 1/2-02	XPX 5/32-N1	XPX 1/4-N3	XPX 1/2-N3
XPX 04-01	XPX 08-02	XPX 12-04	XPX 1/4-03	XPX 1/2-03	XPX 5/32-N2	XPX 5/16-N1	XPX 1/2-N4
XPX 04-02	XPX 08-03		XPX 5/16-01	XPX 1/2-04	XPX 3/16-U	XPX 5/16-N2	
XPX 06-M5	XPX 08-04		XPX 5/16-02		XPX 3/16-N1	XPX 5/16-N3	
XPX 06-M6	XPX 10-01		XPX 5/16-03		XPX 3/16-N2	XPX 3/8-N1	
XPX 06-01	XPX 10-02		XPX 3/8-01		XPX 3/16-N3	XPX 3/8-N2	
XPX 06-02	XPX 10-03		XPX 3/8-02		XPX 1/4-U	XPX 3/8-N3	
XPX 06-03	XPX 10-04		XPX 3/8-03		XPX 1/4-N1	XPX 3/8-N4	

**XPKB**



MODEL(ΦD-T)

Tube(Inch)-Thread(R)
XPKB 04-01
XPKB 04-02
XPKB 06-01
XPKB 06-02
XPKB 06-03
XPKB 08-01
XPKB 08-02
XPKB 08-03


**XPKD**



MODEL(ΦD-T)

Tube(Inch)-Thread(R)	
XPKD 06-04-01	XPKD 3/16-5/32-N1
XPKD 08-04-02	XPKD 1/4-5/32-N1
XPKD 08-06-02	XPKD 5/16-5/32-N2
XPKD 10-08-03	XPKD 5/16-1/4-N2
	XPKD 3/8-5/16-N3


**XPH**



MODEL(ΦD-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)	
XPH 04-M5	XPH 08-01	XPH 12-04	XPH 1/4-05	XPH 5/32-U	XPH 5/16-N3	
XPH 04-M6	XPH 08-02		XPH 1/4-01	XPH 5/32-N1	XPH 3/8-N2	
XPH 04-01	XPH 08-03		XPH 1/4-02	XPH 3/16-U	XPH 3/8-N3	
XPH 04-02	XPH 08-04		XPH 5/16-01	XPH 3/16-N1	XPH 1/2-N3	
XPH 06-M5	XPH 10-02		XPH 5/16-02	XPH 3/16-N2	XPH 1/2-N4	
XPH 06-M6	XPH 10-03		XPH 5/16-03	XPH 1/4-N1		
XPH 06-01	XPH 10-04		XPH 3/8-02	XPH 1/4-N2		
XPH 06-02	XPH 12-02		XPH 3/8-03	XPH 5/16-N1		
XPH 06-03	XPH 12-03			XPH 5/16-N2		

**XPHF**




MODEL(ΦD-T)

Tube(Metric)-Thread(R)			Tube(Inch)-Thread(R)		Tube(Inch)-Thread(NPT)	
XPHF 04-M5	XPHF 08-01	XPHF 12-04	XPHF 1/4-M5	XPHF 5/32-U	XPHF 5/16-N3	
XPHF 04-M6	XPHF 08-02		XPHF 1/4-01	XPHF 5/32-N1	XPHF 3/8-N2	
XPHF 04-01	XPHF 08-03		XPHF 1/4-02	XPHF 3/16-U	XPHF 3/8-N3	
XPHF 04-02	XPHF 08-04		XPHF 5/16-01	XPHF 3/16-N1	XPHF 1/2-N3	
XPHF 06-M5	XPHF 10-02		XPHF 5/16-02	XPHF 3/16-N2	XPHF 1/2-N4	
XPHF 06-M6	XPHF 10-03		XPHF 5/16-03	XPHF 1/4-N1		
XPHF 06-01	XPHF 10-04		XPHF 3/8-02	XPHF 1/4-N2		
XPHF 06-02	XPHF 12-02		XPHF 3/8-03	XPHF 5/16-N1		
XPHF 06-03	XPHF 12-03			XPHF 5/16-N2		

**Pneumatic Tube Fittings**


**XPMF**



MODEL(ΦD-T)

Tube(Metric)-Thread(RC)		Tube(Inch)-Thread(NPT)	
XPMF 04-01	XPMF 10-01	XPMF 5/32-N1	XPMF 3/8-N3
XPMF 04-02	XPMF 10-02	XPMF 3/16-N1	XPMF 1/2-N3
XPMF 06-01	XPMF 10-03	XPMF 3/16-N2	XPMF 1/2-N4
XPMF 06-02	XPMF 10-04	XPMF 1/4-N1	
XPMF 06-03	XPMF 12-02	XPMF 1/4-N2	
XPMF 08-01	XPMF 12-03	XPMF 5/16-N1	
XPMF 08-02	XPMF 12-04	XPMF 5/16-N2	
XPMF 08-03	XPMF 14-04	XPMF 5/16-N3	
XPMF 08-04	XPMF 16-04	XPMF 3/8-N2	

**XPGJ**



MODEL(ΦD1-ΦD2)

Tube(Metric)-Thread(R)	Tube(Inch)-Thread(R)	Tube(Inch)-Thread(NPT)
XPGJ 06-04	XPGJ 08-1/4	XPGJ 1/4-5/32
XPGJ 08-04	XPGJ 10-1/4	XPGJ 5/16-5/32
XPGJ 08-06	XPGJ 10-5/16	XPGJ 5/16-1/4
XPGJ 10-06	XPGJ 12-1/4	XPGJ 3/8-1/4
XPGJ 10-08	XPGJ 12-5/16	XPGJ 3/8-5/16
XPGJ 12-06		XPGJ 1/2-1/4
XPGJ 12-08		XPGJ 1/2-5/16
XPGJ 12-10		XPGJ 1/2-3/8

**XPLJ**



MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPLJ 04	XPLJ 5/32
XPLJ 06	XPLJ 3/16
XPLJ 08	XPLJ 1/4
XPLJ 10	XPLJ 5/16
XPLJ 12	XPLJ 3/8
	XPLJ 1/2


**XPLGJ**



MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPLGJ 06-04	XPLGJ 3/16-5/32
XPLGJ 08-06	XPLGJ 1/4-5/32
XPLGJ 10-08	XPLGJ 1/4-3/16
XPLGJ 12-10	XPLGJ 5/16-1/4
	XPLGJ 3/8-5/16
	XPLGJ 1/2-3/8


**XPYJ**



MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPYJ 04	XPYJ 5/32
XPYJ 06	XPYJ 3/16
XPYJ 08	XPYJ 1/4
XPYJ 10	XPYJ 5/16
XPYJ 12	XPYJ 3/8
	XPYJ 1/2

**XPWJ**



MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPWJ 06-04	XPWJ 1/4-5/32
XPWJ 08-06	XPWJ 5/16-1/4
XPWJ 10-08	XPWJ 3/8-5/16
XPWJ 12-10	XPWJ 1/2-3/8

**XPIJ**



MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPIJ 04	XPIJ 5/32
XPIJ 06	XPIJ 3/16
XPIJ 08	XPIJ 1/4
XPIJ 10	XPIJ 5/16
XPIJ 12	XPIJ 3/8
XPIJ 16	XPIJ 1/2

**XPKJ**





MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPKJ 06-04	XPKJ 3/16-5/32
XPKJ 08-04	XPKJ 1/4-5/32
XPKJ 08-06	XPKJ 5/16-5/32
XPKJ 10-08	XPKJ 5/16-3/16
XPKJ 10-08	XPKJ 5/16-1/4
	XPKJ 3/8-1/4
	XPKJ 3/8-5/16



**Pneumatic Tube Fittings**

<b>XPDJ</b>	MODEL( $\Phi$ D)		<b>XPSJ</b>	MODEL( $\Phi$ D1- $\Phi$ D2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPDJ 04	XPDJ 08-06		XPSJ 06-04	XPSJ 1/4-5/32
	XPDJ 06	XPDJ 10-08		XPSJ 08-06	XPSJ 5-16-1/4
	XPDJ 08	XPDJ 12-10		XPSJ 10-08	XPSJ 3/8-5-16
	XPDJ 10			XPSJ 12-10	XPSJ 1-2-3/8
	XPDJ 12				
	XPDJ 06-04				



<b>XPTJ</b>	MODEL( $\Phi$ D1- $\Phi$ D2)		<b>XPP</b>	MODEL( $\Phi$ D)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPTJ 06-04	XPTJ 1/4-5/32		XPP 04	XPP 5/32
	XPTJ 08-06	XPTJ 5/16-1/4		XPP 06	XPP 3/16
	XPTJ 10-08	XPTJ 3/8-5/16		XPP 08	XPP 1/4
	XPTJ 12-10	XPTJ 1/2-3/8		XPP 10	XPP 5/16
				XPP 12	XPP 3/8
		XPP 16	XPP 1/2		

<b>XPIG</b>	MODEL( $\Phi$ D1- $\Phi$ D2)		<b>XPM</b>	MODEL( $\Phi$ D)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPIG 06-04	XPIG 3/16-5/32		XPM 04	XPM 5/32
	XPIG 08-06	XPIG 1/4-5/32		XPM 06	XPM 3/16
	XPIG 10-08	XPIG 1/4-3/16		XPM 08	XPM 1/4
	XPIG 12-10	XPIG 5/16-1/4		XPM 10	XPM 5/16
	XPIG 16-12	XPIG 3/8-5/16		XPM 12	XPM 3/8
		XPIG 1/2-3/8		XPM 14	XPM 1/2
		XPM 16			

<b>XPZA</b>	MODEL( $\Phi$ D)		<b>XPKG</b>	MODEL( $\Phi$ D1- $\Phi$ D2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPZA 04	XPZA 5/32		XPKG 06-04	XPKG 3/16-5/32
	XPZA 06	XPZA 3/16		XPKG 08-04	XPKG 1/4-5/32
	XPZA 08	XPZA 1/4		XPKG 08-06	XPKG 5/16-5/32
	XPZA 10	XPZA 5/16		XPKG 10-06	XPKG 3/16-3/16
	XPZA 12	XPZA 3/8		XPKG 10-08	XPKG 5/16-1/4
		XPZA 1/2			XPKG 3/8-1/4
			XPKG 3/8-5/16		



<b>XPKE</b>	MODEL( $\Phi$ D)		<b>XPLM</b>	MODEL( $\Phi$ D)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPKE 04	XPKE 5/32		XPLM 04	
	XPKE 06	XPKE 3/16		XPLM 06	
	XPKE 08	XPKE 1/4		XPLM 08	
		XPKE 5/16		XPLM 10	
				XPLM 12	

**Pneumatic Tube Fittings**

<b>XPHT(2)</b>	MODEL( $\Phi$ D-T)		<b>XPLGJ</b>	MODEL( $\Phi$ D-T)	
	Tube(Metric)-Thread(R)	Tube(Metric)-Thread(R)		Tube(Metric)-Thread(R)	Tube(Metric)-Thread(R)
	XPHT04 -01(2)	XPHT08 -04(2)		XPHT04 -01(3)	XPHT08 -04(3)
	XPHT04 -02(2)	XPHT10 -01(2)		XPHT04 -02(3)	XPHT10 -01(3)
	XPHT06 -01(2)	XPHT10 -02(2)		XPHT06 -01(3)	XPHT10 -02(3)
	XPHT06 -02(2)	XPHT10 -03(2)		XPHT06 -02(3)	XPHT10 -03(3)
	XPHT06 -03(2)	XPHT10 -04(2)		XPHT06 -03(3)	XPHT10 -04(3)
	XPHT08 -01(2)	XPHT12 -02(2)		XPHT08 -01(3)	XPHT12 -02(3)
	XPHT08 -02(2)	XPHT12 -03(2)		XPHT08 -02(3)	XPHT12 -03(3)
	XPHT08 -03(2)	XPHT12 -04(2)		XPHT08 -03(3)	XPHT12 -04(3)

<b>XPPF</b>	MODEL( $\Phi$ D)		<b>XPU</b>	MODEL( $\Phi$ D)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPPF04			XPU 04	XPU 5/32
	XPPF06			XPU 06	XPU 3/16
	XPPF07			XPU 08	XPU 1/4
	XPPF08			XPU 10	XPU 5/16
	XPPF10			XPU 12	XPU 3/8
	XPPF12			XPU 14	XPU 1/2
		XPU 16			

<b>XPV</b>	MODEL( $\Phi$ D)		<b>XPE</b>	MODEL( $\Phi$ D)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPV 04	XPV 5/32		XPE 04	XPE 5/32
	XPV 06	XPV 3/16		XPE 06	XPE 3/16
	XPV 08	XPV 1/4		XPE 08	XPE 1/4
	XPV 10	XPV 5/16		XPE 10	XPE 5/16
	XPV 12	XPV 3/8		XPE 12	XPE 3/8
	XPV 14	XPV 1/2		XPE 14	XPE 1/2
	XPV 16			XPE 16	

<b>XPY</b>	MODEL( $\Phi$ D-T)		<b>XPG</b>	MODEL( $\Phi$ D1- $\Phi$ D2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPY 04	XPY 5/32		XPG 06-04	XPG 3/16-5/32
	XPY 06	XPY 3/16		XPG 08-04	XPG 1/4-5/32
	XPY 08	XPY 1/4		XPG 08-06	XPG 1/4-3/16
	XPY 10	XPY 5/16		XPG 10-06	XPG 5/16-1/4
	XPY 12	XPY 3/8		XPG 10-08	XPG 3/8-5/16
		XPY 1/2		XPG 12-10	XPG 1/2-3/8
		XPG 16-12			
		XPG 16-14			

<b>XPGE</b>	MODEL( $\Phi$ D1- $\Phi$ D2)		<b>XPEG</b>	MODEL( $\Phi$ D1- $\Phi$ D2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPGE 06-04	XPGE 1/4-5/32		XPEG 06-04	XPEG 1/4-5/32
	XPGE 08-06	XPGE 5/16-1/4		XPEG 08-06	XPEG 5/16-1/4
	XPGE 10-08	XPGE 3/8-5/16		XPEG 10-08	XPEG 3/8-5/16
	XPGE 12-10	XPGE 1/2-3/8		XPEG 12-10	XPEG 1/2-3/8
	XPGE 16-12			XPEG 16-12	