






Pipe Joint Fittings




XQPC	MODEL(ΦD-T)					
	Tube(Metric)-Thread(R)			Tube(Metric)-Thread(G)		
	ΦD	T		ΦD	T	
	XQPC 04-01	XQPC 08-02	XQPC 12-02	XQPC 04-G01	XQPC 08-G02	XQPC 12-G02
	XQPC 04-02	XQPC 08-03	XQPC 12-03	XQPC 04-G02	XQPC 08-G03	XQPC 12-G03
	XQPC 06-01	XQPC 10-02	XQPC 12-04	XQPC 06-G01	XQPC 10-G02	XQPC 12-G04
	XQPC 06-02	XQPC 10-03		XQPC 06-G02	XQPC 10-G03	
	XQPC 08-01	XQPC 10-04		XQPC 08-G01	XQPC 10-G04	
	Male Straight					

XQPL	MODEL(ΦD-T)					
	Tube(Metric)-Thread(R)			Tube(Metric)-Thread(G)		
	ΦD	T		ΦD	T	
	XQPL 04-01	XQPL 08-02	XQPL 12-02	XQPL 04-G01	XQPL 08-G02	XQPL 12-G02
	XQPL 04-02	XQPL 08-03	XQPL 12-03	XQPL 04-G02	XQPL 08-G03	XQPL 12-G03
	XQPL 06-01	XQPL 10-02	XQPL 12-04	XQPL 06-G01	XQPL 10-G02	XQPL 12-G04
	XQPL 06-02	XQPL 10-03		XQPL 06-G02	XQPL 10-G03	
	XQPL 08-01	XQPL 10-04		XQPL 08-G01	XQPL 10-G04	
	Male Elbow					




XQPCF	MODEL(ΦD-T)					
	Tube(Metric)-Thread(R)			Tube(Metric)-Thread(G)		
	ΦD	T		ΦD	T	
	XQPCF 04-01	XQPCF 08-02	XQPCF 12-02	XQPCF 04-G01	XQPCF 08-G02	XQPCF 12-G02
	XQPCF 04-02	XQPCF 08-03	XQPCF 12-03	XQPCF 04-G02	XQPCF 08-G03	XQPCF 12-G03
	XQPCF 06-01	XQPCF 10-02	XQPCF 12-04	XQPCF 06-G01	XQPCF 10-G02	XQPCF 12-G04
	XQPCF 06-02	XQPCF 10-03		XQPCF 06-G02	XQPCF 10-G03	
	XQPCF 08-01	XQPCF 10-04		XQPCF 08-G01	XQPCF 10-G04	
	Female Elbow					

XQPT	MODEL(ΦD-T)					
	Tube(Metric)-Thread(R)			Tube(Metric)-Thread(G)		
	ΦD	T		ΦD	T	
	XQPT 04-01	XQPT 08-02	XQPT 12-02	XQPT 04-G01	XQPT 08-G02	XQPT 12-G02
	XQPT 04-02	XQPT 08-03	XQPT 12-03	XQPT 04-G02	XQPT 08-G03	XQPT 12-G03
	XQPT 06-01	XQPT 10-02	XQPT 12-04	XQPT 06-G01	XQPT 10-G02	XQPT 12-G04
	XQPT 06-02	XQPT 10-03		XQPT 06-G02	XQPT 10-G03	
	XQPT 08-01	XQPT 10-04		XQPT 08-G01	XQPT 10-G04	
	Male Tee					

XQPD	MODEL(ΦD-T)					
	Tube(Metric)-Thread(R)			Tube(Metric)-Thread(G)		
	ΦD	T		ΦD	T	
	XQPD 04-01	XQPD 08-02	XQPD 12-02	XQPD 04-G01	XQPD 08-G02	XQPD 12-G02
	XQPD 04-02	XQPD 08-03	XQPD 12-03	XQPD 04-G02	XQPD 08-G03	XQPD 12-G03
	XQPD 06-01	XQPD 10-02	XQPD 12-04	XQPD 06-G01	XQPD 10-G02	XQPD 12-G04
	XQPD 06-02	XQPD 10-03		XQPD 06-G02	XQPD 10-G03	
	XQPD 08-01	XQPD 10-04		XQPD 08-G01	XQPD 10-G04	
	Run Tee					

XQPUC	MODEL(ΦD)	XQPUL	MODEL(ΦD)	XQPUT	MODEL(ΦD)
	Tube(Metric)		Tube(Metric)		Tube(Metric)
	XQPUC 04		XQPUL 04		XQPUT 04
	XQPUC 06		XQPUL 06		XQPUT 06
	XQPUC 08		XQPUL 08		XQPUT 08
	XQPUC 10		XQPUL 10		XQPUT 10
	XQPUC 12		XQPUL 12		XQPUT 12
Union Straight					
Union Elbow					
Union Tee					

Pipe Joint Fittings

XQPZA	MODEL(ΦD)	XQPM	MODEL(ΦD)	XQS	MODEL(ΦD-T)
	Tube(Metric)		Tube(Metric)		Tube(Metric)
	ΦD		ΦD		ΦD
	XQPZA 04		XQPM 04		XQS 04
	XQPZA 06		XQPM 06		XQS 06
	XQPZA 08		XQPM 08		XQS 08
	XQPZA 10		XQPM 10		XQS 10
	XQPZA 12		XQPM 12		XQS 12
	Union Cross				
Bulkhead Union					
Nut					

XQI	MODEL(ΦD)
	Tube(Metric)
	ΦD
	XQI 04
	XQI 06
	XQI 08
	XQI 10
	XQI 12


Pipe Fittings


Feature

- When involved in factory maintenance or Plant installation, it's often difficult to be certain which size of fittings will be required. Our Pipe fittings provide a cost effective solution to solve this problem.

Specification

Material	Nickel-plated Brass
Threads	BSPT, BSPP, NPT, Metric threads
Pressure	(See tube)
Fluid	Compressed air
Temperature	(See data of used tubing)

XPSM	MODEL(ΦT1-ΦT1)						
	Thread(R)T1-Thread(R)T2		Thread(NPT)T1-Thread(NPT)T2		Thread(G)T1-Thread(G)T2		
	ΦD	T	ΦD	T	ΦD	T	
	XPSM 01-01	XPSM 06-06	XPSM N01-N01	XPSM N06-N06	XPSM G01-G01	XPSM G06-G06	
	XPSM 02-02	XPSM 06-04	XPSM N02-N02	XPSM N06-N04	XPSM G02-G02	XPSM G06-G04	
	XPSM 02-01	XPSM 06-03	XPSM N02-N01	XPSM N06-N03	XPSM G02-G01	XPSM G06-G03	
	XPSM 03-03	XPSM 06-02	XPSM N03-N03	XPSM N06-N02	XPSM G03-G03	XPSM G06-G02	
	XPSM 03-02	XPSM 08-08	XPSM N03-N02	XPSM N08-N08	XPSM G03-G02	XPSM G08-G08	
	XPSM 03-01	XPSM 08-06	XPSM N03-N01	XPSM N08-N06	XPSM G03-G01	XPSM G08-G06	
	XPSM 04-04	XPSM 08-04	XPSM N04-N04	XPSM N08-N04	XPSM G04-G04	XPSM G08-G04	
	XPSM 04-03	XPSM 08-03	XPSM N04-N03	XPSM N08-N03	XPSM G04-G03	XPSM G08-G03	
	XPSM 04-02		XPSM N04-N02		XPSM G04-G02		
	XPSM 04-01		XPSM N04-N01		XPSM G04-G01		
	Straight Male						

XPSF	MODEL(ΦT1-ΦT1)						
	Thread(R)T1-Thread(R)T2		Thread(NPT)T1-Thread(NPT)T2		Thread(G)T1-Thread(G)T2		
	ΦD	T	ΦD	T	ΦD	T	
	XPSF 01-01	XPSF 04-01	XPSF N01-N01	XPSF N04-N01	XPSF G01-G01	XPSF G04-G01	
	XPSF 02-02	XPSF 06-06	XPSF N02-N02	XPSF N06-N06	XPSF G02-G02	XPSF G06-G06	
	XPSF 02-01	XPSF 06-04	XPSF N02-N01	XPSF N06-N04	XPSF G02-G01	XPSF G06-G04	
	XPSF 03-03	XPSF 06-03	XPSF N03-N03	XPSF N06-N03	XPSF G03-G03	XPSF G06-G03	
	XPSF 03-02	XPSF 06-02	XPSF N03-N02	XPSF N06-N02	XPSF G03-G02	XPSF G06-G02	
	XPSF 03-01	XPSF 08-08	XPSF N03-N01	XPSF N08-N08	XPSF G03-G01	XPSF G08-G08	
	XPSF 04-04	XPSF 08-06	XPSF N04-N04	XPSF N08-N06	XPSF G04-G04	XPSF G08-G06	
	XPSF 04-03	XPSF 08-04	XPSF N04-N03	XPSF N08-N04	XPSF G04-G03	XPSF G08-G04	
	XPSF 04-02	XPSF 08-03	XPSF N04-N02	XPSF N08-N03	XPSF G04-G02	XPSF G08-G03	
	Straight Female						